

SPOTNAILS

1 | Stringer Board to Block



PN65M PN70 PN80 PN90

2 | Top Deck Board to Stringer Board & 3 | Bottom Deck to Block



PN90 PN100B

4 | Bottom Deck Board to Stringer & 5 | Top Deck Board to Stringer



PN57 / PN58 / PN59 PN65M PN70 PN80 PN90

6 | Disassembly



DN20-60

7 | Deck Board to Stringer Board Reattachment (Clinching)



PN70CL

8 | Deck Board to Block Reattachment



PN90 PN100B

9 | Deck Board to Stringer Reattachment



PN57 / PN58 / PN59 PN65M PN70

10 | Split Stringer Repair



CFN-15S SN40 Series





PN80 PN90 SN50 Series


Jumbo Magazine Assemblies Are Available For Selected Tool Models



PN70PAL-JM PN80PAL-JM PN70PAL




Automation: PN70PAL nailing decks to blocks




PN90 nailing bottom decks to pallet blocks




Automation: PN80PAL nailing decks to stringers



DN20-60 removing nails from a deck board



PN70CL clinching decks to stringer boards on pallet repair



CFN15S fixing a split stringer